


ORC-ALARM-16-DIN

35mm Din Rail Bracket for ALARM 16 Board

Installation Manual

1. Connect the DIN bracket at the top of the ORC-ALARM-16 then push down the DIN bracket at the bottom "Click"



2. Connect the DIN bracket at the top of the Din Rail, then push back the DIN bracket at the bottom "Click"

